








## MODEL 163

- 1 Fuel filler flap  
 2 Outer screws  
 3 Inner screws  
 4 Fuel filler fitting  
 5 Screws  
 6 Connector  
 M14/10 Filler flap CL actuating motor



P80.20-0478-06

|   | Removal, installation                           |   |                  |
|--|---|---|------------------|
| 1  | Remove paneling on C-pillar                     |  Remove paneling on left C-pillar   | AR68.30-P-4490GH |
| 2  | Remove fuel filler flap (1)                     |   |                  |
| 3  | Unscrew outer screws (2) on fuel filler         |  <b>When installing:</b> Ensure that rubber seal is properly seated                  |                  |
| 4  | Unscrew inner screws (3) on fuel filler         |   |                  |
| 5  | Unscrew filler flap CL actuating motor (M14/10) |  Push filler fitting to right and unscrew screws from filler flap CL actuating motor |                  |
| 6  | Disconnect connector (6)                        |   |                  |
| 7  | Reinstall in opposite order                     |   |                  |
| 8  | Check for proper function                       |  Actuate central locking with fuel filler flap open                                  |                  |