

MODEL 163.113 /128 /136 /154 /157 /172 /175 with CODE (U49) Styling package

MODEL 163.174

- 1 Cover
- 2 Bolt
- 3 Fog lamp



P82.10-2830-06

☒ ☒	Remove/Install		
1	Remove cover (1)		
2	Unscrew bolt (2)		
3	Remove fog lamp (3) from bumper		
4	Disconnect connector		
5	Install in the reverse order		