


AN68.30-P-0001-02A	Modify roof paneling for installing handle and clamping strap mount	Model 163.113 /154 #A up to 289564, #X up to 754619 Model 163.136/ 172 with code (847), 3rd seat row	
--------------------	---	--	--

**Nm** Handles

Number	Designation	MODEL Series 163
BA68.70-P-1001-02A	Screw for pivot handle/mount on roof frame	Nm 2.5

- 1 Remove clothes hook and accessory hook.
- 2 Position template (1) to roof paneling.
- i** Fasten template with adhesive tape.
- 3 Mark points which must be cut out for installing the handle.
- 4 Remove template (1).
- 5 Cut out cutouts for handle.




P68.30-2055-10

**Only on vehicles with safety standard FMVSS201.**

- 6.1 Install shock absorber (5).
- D** Danger of cracks. Carefully pull roof paneling downward and install shock absorber between roof paneling and roof frame.

**i** The flat side of the shock absorber (5) points in the direction of the roof frame.




P68.30-2170-10

- 7 Install accessory hook (2), clamping strap mount (3) and pivot handle (4).

**i** On vehicles with FMVSS201 install special clamping strap mounts and pivot handles with screws (6) Nm .

- 8 Repeat on opposite side.



P68.30-2056-10