


MODEL 163.113 /154 #A as of 289565,
163.113 #X as of 754620,
163.128 /154 /157 /175 except CODE (U49) Styling package



P88.20-2203-09


	Remove/install		
1.1	Remove brush guard together with underride guard	If installed. 	AR88.30-P-2000-01GI *BA88.30-P-1003-01A *BA88.30-P-1015-01A *BA88.30-P-1016-01A
2	Remove fog lamps		AR82.10-P-5103GI
3	Remove front bumper grille.	Carefully remove bumper grille so that bumper grille and mounts cannot be damaged. Remove with correspondingly formed hook. Pulling hook	*140589023300
4	Remove outdoor temperature sensor from bumper.		
5	Unscrew screws (1)	At front side of bumper. 	*BA88.20-P-1009-01B
6	Unscrew bolt (2)	At inner bumper corners. 	*BA88.20-P-1002-01B
7	Unscrew nuts (3).	At inner sides of bumper. 	*BA88.20-P-1001-01B
8	Loosen side mount on bumper from body.	Loosen only one side. Move mount toward inside.	
9	Remove bumper toward front.	Do not damage paint. Do not damage Parktronic connection cable if present. Installation: Observe correct installation position of fog lamps.	
10.1	Disconnect connector from Parktronic system	Only with Parktronic system (PTS), code 220a.	
11	Install in the reverse order		

Detachable body components, underride guard

Number	Designation		Model 163 as of 1.9.01
BA88.30-P-1003-01A	Screw, mount on brush guard	Nm	25
BA88.30-P-1015-01A	Nut, underride guard to bracket	Nm	49
BA88.30-P-1016-01A	Bolt, front section of underride guard to rear section of underride guard	Nm	49

Nm Bumper

Number	Designation		Model 163
BA88.20-P-1001-01B	Nut, front bumper on outer mount	Nm	8
BA88.20-P-1002-01B	Screw for front bumper on inner mount	Nm	1.5
BA88.20-P-1009-01B	Screw for front bumper on mount	Nm	8



Pulling hook