
## AR61.20-P-1105GH

## MODEL163.172 with ENGINE 113.942MODEL163.174 with ENGINE 113.981MODEL163.175 with ENGINE 113.965

- 1 Engine compartment paneling
- 2 Grub screw
- 3 Plastic clips



P61.20-2017-12

XX	Remove/Install	
1	Remove grub screws (2) of plastic clips (3)	i 6 grub screws pins.
		<b>i</b> Installation: Check grub screws, replace
		if necessary.
2	Pull out plastic clips (3)	i Installation: Check plastic clips, replace
		if necessary.
3	Remove engine compartment panel (1)	<b>i</b> Installation: Ensure that engine compartment panel is positioned correctly.
4	Install in the reverse order	