

The electronic compass (B26) determines the current **route** of the vehicle using the **earth's magnetic field** and passes the appropriate data to the trip computer control module (N41) via a two-wire interface (RS485).

The compass has a calibration mode to allow the route to be determined as accurately as possible. In this mode the compass can be adapted to the magnetic conditions around the vehicle.