
OS00.00-P-1001-01A	Releasing gas from gas strut and emptying		
⚠ Danger!	Risk of injury from drilling gas-filled	Wear safety glasses and face mask.	AS00.00-Z-0006-01A
	subassemblies or components (gas filling non-		
	combustible)		

- 1 Clamp gas-operated strut in machine vise of pillar drilling machine.
- Drill gas-operated strut approx. 20 mm (dimension a) from bottom of gas-operated strut 4 with a 3 mm drill (arrow). Drill with as little force as possible.
- 3 Unclamp gas-operated strut, pump gas-operated strut empty by pressing conrod in several times.
- i Observe regulations for disposal of hydraulic oil.
- 4 Dispose of gas-operated strut (worn part).



P88.40-0216-01