


MODEL 163

- 1 Cover
 2 Instrument cluster housing
 3 Symbol strip



P54.30-0631-06

☒ ☒	Removing, installing		
1	Remove instrument cluster		AR54.30-P-6015GH
2	Unclip retaining lugs (arrows)	i Installation: The retaining lugs must lock fully in position.	
3	Remove cover (1) from instrument cluster housing (2)	i The symbol strips (3) may fall out sideways. i Installation: Pay attention to vehicle equipment when replacing symbol strips. Ensure the adjusting knobs for the odometer and electronic clock are seated correctly.	
4	Install in reverse order		