
MODEL 163.172 with ENGINE 113.942 MODEL 163.174 with ENGINE 113.981 MODEL 163.175 with ENGINE 113.965

- 1 Engine compartment paneling
- 2 Grub screw
- 3 Plastic clips



P61.20-2017-12

XX	Remove/Install		
1	Remove grub screws (2) of plastic clips (3)	i 6 grub screws pins.	
		i Installation: Check grub screws, replace	
		if necessary.	
2	Pull out plastic clips (3)	i Installation: Check plastic clips, replace	
		if necessary.	
3	Remove engine compartment panel (1)	i Installation: Ensure that engine compartment panel is positioned correctly.	
4	Install in the reverse order		