

GF83.10-P-2138GC	Air inlet, location/function	23.6.98
------------------	------------------------------	---------

MODEL 163, 168

	Air inlet, location	Model 168 Model 163	GF83.10-P-2100-01GC GF83.10-P-2100-01GH
	Air inlet, function	The fresh air required for ventilation flows through the air inlet to the heater/air conditioning housing.	