


The air inlet (1) is located at the bottom of the windshield.



P83.10-2013-06