

MODEL 163 up to 31.8.01,  
168

	Blower, location	Model 168 Model 163	GF83.10-P-2102-01GC GF83.10-P-2102-01GH
	Blower, task	In fresh air mode the blower (M2) draws in fresh air, and in recirculating air mode it draws in air from the vehicle interior into the heater or evaporator housing via the recirculating air flap.	
	Blower design	The blower (M2) is designed as a twin-pipe radial blower.	
	Blower, function	Model 168	GF83.10-P-2102-02GC
		Model 163	GF83.10-P-2102-02GH