
## GF83.10-P-2104-01GH Dust filter, location

The dust filter (1) is behind the instrument panel bottom section at the passenger side in the heater/evaporator housing.



n

P83.10-0368-06