

GF83.10-P-2145GC	Front footwell air outlet, location/purpose/function	23.6.98
------------------	--	---------

MODEL 163, 168

	Front footwell air outlet, location	Model 168 Model 163	GF83.10-P-2109-02GC GF83.10-P-2109-02GH
	Front footwell air outlet, purpose	The front footwell air outlet serves for ventilation of the left and right front footwell.	
	Front footwell air outlet, function		GF83.10-P-2109-01GC