


MODELS 163 up to 31.8.01,
 168 up to 28.2.01 with CODE (580) Air conditioning or Tempmatic for USA
MODEL 163 as of 1.9.01 with code (580a) Automatic air conditioning

Shown on model 163 as of 1.09.01

*M2/5 Fresh air/recirculated air flap
 actuator*



P83.10-2195-06

	Fresh air/recirculated air flap actuator, position	The fresh air/recirculated air flap actuator (M2/5) is located on the side of the air inlet duct of the air conditioner housing. Model 168 Model 163, up to 31.08.01	GF83.30-P-2105-01GC GF83.30-P-2105-01GH
	Fresh air/recirculated air flap actuator, task	The fresh air/recirculated air flap actuator serves to cut off the supply of fresh air when required.	
	Fresh air/recirculated air flap actuator, function	Model 168	GF83.30-P-2105-02GC
		Model 163, up to 31.08.01 Model 163 as of 1.09.01	GF83.30-P-2105-02GH GF83.30-P-2105-02GI