

MODEL 163, 168

	Defroster nozzle, location	Model 168 Model 163	GF83.10-P-2106-01GC GF83.10-P-2106-01GH
	Defroster nozzle, purpose	The defroster nozzles serve for ventilation and keeping the windshield and side windows from fogging up.	
	Defroster nozzle, function	The air supply to the windshield defroster nozzles can be opened and closed with the air distribution switch. Separate adjustment is not possible. Blended air exits from the defroster nozzles.	