

GF83.10-P-2150GC	Side nozzle, location/purpose/function	24.6.98
------------------	--	---------

MODEL 163, 168

	Side nozzle, location	Model 168 Model 163	GF83.10-P-2108-02GC GF83.10-P-2108-02GH
	Side nozzle, purpose	The left and right side nozzles serve for specific guidance and distribution of the air in the passenger compartment on the driver and passenger sides.	
	Side nozzle, function	Model 168	GF83.10-P-2108-01GC
		Model 163	GF83.10-P-2108-01GH