


Function

The side nozzle (3) can be adjusted infinitely or opened and closed completely with the dial.

The air exit direction can be adjusted upward, downward, to the left, to the right or middle as desired with the louver system.

Heated/cooled air exits through the side nozzle (3).



P68.10-0513-01