



MODEL 163

Fuses 1-42
Relay k1-k32



P54.15-0438-06

Overview of fuse and relay module in right front footwell



P54.15-2486-12

	Fuse and relay box, fuses, relay holder	Engines 612.963 and 628.963	GF54.15-P-1255-12G
	Fuse and relay box, fuses, relay holder	up to 31.08.01	GF54.15-P-1255-15GH
	Fuse and relay box, fuses, relay holder	as of 01.09.01	GF54.15-P-1255-15GA
	Fuse and relay box, fuses, relay holder	Fuse and module box in right front footwell	GF54.15-P-1255-15GI
	Fuse and relay box, relay/relay holder	up to 31.08.01	GF54.15-P-1255-18GH
	Fuse and relay box, relay/relay holder	as of 01.09.01	GF54.15-P-1255-18GA
	Fuse and relay box, relay/relay holder	Fuse and module box in right front footwell	GF54.15-P-1255-18GI