

Warning buzzer

- D Light reminder and parking brake reminder
 - D Key reminder I
 - D Seat belt reminder
 - for approx. 6 s I , M , H and Korea
 - for approx. 12 s G
 - The warning tone is interrupted as soon as the seat belt buckle is inserted.
 - D Warning tone for a shortage of oil
 - D Vehicle speed warning G > 120 km/h, v-limit warning (cruise control)
 - D In addition the symbol for vehicle speed warning appears in the instrument cluster with multi-function display.
- D On model 163 a warning tone sounds for approx. 5 seconds if the CAN signal is unusable.
 - D Model 168 with automatic clutch system features an audible gear warning.
It sounds if a gear is engaged at the same time as the driver's door is opened. Brake and accelerator pedal must not be operated.