AR33.10-P-0100-01BV Attach engine support bracket and raise en	gine
--	------

## Commercially available tools (see Workshop Equipment Manual)

Number	Designation	Make (e. g.)	Order number
WH58.30-Z-1013-07A  Engine lifting device for ML-class	Engine lifting device for ML-class	SPX (Europe) AG	0334.01
	Kent-Moore Division		
	attn.: Mr Hodel		
	Oberneuhofstr. 1		
	CH-6340 Baar		
	Fax:+4141/761-43-43		
	Fax:+4141/761-07-27		
	1		
	SPX Corporation		
	OE Tool+Equipment		
	28635 Mound Road		
	warren, MI 48092		
		Tel: 1-800-345-2233	
		Fax: 1-800-578-7375	

 $\fbox{\textbf{i}}$  The engine support bracket (1) is positioned with its support surfaces resting on the left and right-side fenders' inside seams (arrows).

i During installation it is important to proceed with caution to avoid damage to the vehicle paintwork.

1 Lift engine by the front suspension hook.

Shown on model 163 with engine 112.942



P58.30-2004-01