

AF80.57-P-6406A	Engine sometimes fails to start and fault message "Start Error" appear in the instrument cluster	13.8.04
-----------------	--	---------

MODEL 163.136 /154 /172 #A as of 145273,
163.136 /154 /172 #X as of 708319,
163.113 /128 /157 /174 /175

Operation no. of operation texts or standard texts and flat rates

Category	Op. no.	Operation text	Time	Acc. no.	Code
P	541011	Perform quick test	004 WU	---	---
P	805030	Replace drive authorization system (DAS [FBS]) control unit (after check)	006 WU	---	---

Damage code	Cause	Remedy	
82 801 90	i When the ignition is switched on (circuit 15), the engine control unit sends a start enable request to the DAS [FBS] control unit. If during this request circuit 15 is switched off or interrupted before the DAS [FBS] control unit could respond, the variable code sent the first time is used again the next time circuit 15 is switched on, since the original request is saved by the DAS [FBS] control.	1 Replace the DAS [FBS] control unit.	AR54.21-P-1300GH
	i The fault message "Start Error" appears in instrument cluster.	i When ordering a new control unit, please specify the chassis number.	

Parts ordering notes

Part no.	Designation	Quantity
163 545 07 16	FBS control unit	1