



- A1 Instrument cluster
- B14 Outside temperature indicator temperature sensor
- M3/3b1 Fuel tank sensor
- N3 Injection system control module
- N47 Traction systems control module
- N78 Transfer case control module
- S97/1 Steering lock switch



P54.30-0738-06

**As of 3.98 also:**

- S41 Electronic switch for coolant level indicator



P54.30-2690-06