


MODEL 463.200 /204 /206 /207 /208 /209 /220 /221 /224 /225 /227 /228 /230 /231 /232 /233 /240 /241 /300 /304 /307 /308 /320 /321 /324 /325 /327 /328 /330 /331


- 1 Cover strip
- 2 Left speaker cover
- 3 Right speaker cover
- 4 Right speaker (left, no illustration)



P82.62-0304-06

<input type="checkbox"/> <input type="checkbox"/>	Remove/install		
1.1	Screw off trim strip (1) on left and right (arrow)	Model 463 up to 4.94	
1.2	Press out cover strip (1) on left and right	Model 463 from 5.94 to 30.11.00.	*110589035900
2	Remove loudspeaker cover (2, 3)		
3	Remove loudspeaker (4)		
4	Disconnect connector (H4/9x1 and H4/10x1)		
5	Install in the reverse order		

Special tools



110 589 03 59 00

Assembly wedge