


MODEL 163.136 /154 /172 #A as of 145273,
163.136 /154 /172 #X as of 708319,
163.113 /128 /157 /174 /175

- 1 Inside rearview mirror
2 Automatic dimming connector

B38 Rain sensor



P68.40-2042-06

☒ ☒	Remove/install		
1	Turn inside rearview mirror (1) 90° and press against mirror housing at side.	⚠ Danger of breaking windshield. Do not damage rain sensor (B38), if present.	
2.1	Disconnect automatic dimming connector (2).	ℹ Only with automatically dimming inside rearview mirror, code 249a.	
3	Install in the reverse order		