








AR98.00-P-0700A	Paint coat repair of leather covers	23.11.93
-----------------	-------------------------------------	----------

MODEL 124, 126, 129, 140, 163, 168, 170, 201, 202, 203, 208, 209, 210, 211, 215, 220, 230, 240, 414, 463.200 /204 /206 /207 /208 /209 /220 /221 /224 /225 /227 /228 /230 /231 /232 /233 /240 /241 /243 /244 /245 /246 /247 /248 /249 /250 /254 /270 /271 /300 /304 /307 /308 /309 /320 /321 /322 /323 /324 /325 /327 /328 /330 /331 /332 /333

 Danger!	Risk of explosion from paint vapors igniting. Paint fumes are poisonous when inhaled.	No smoking! No open flames! Use respiratory protection, protective clothing, gloves, safety goggles and skin cream. Ensure that the area is well ventilated.	AS98.00-Z-0002-01A
1	Clean the repair area	 Use a clean cloth soaked in pure benzine. Then leave to dry.	
2	Lightly spray damaged leather surface with thinner	 This causes the top coat to swell and improves the adhesion of the leather paint. Wait for approx. 5 to 10 min.	
3	Carefully mask off adjacent surfaces		
4	Apply leather paint	 Stir leather paint thoroughly before use (shaking is not sufficient). Leather paint	*BR00.45-Z-1025-04A
5	Spray on leather paint	 The repainting in another color and the painting of entire leather coverings is not permitted for reasons of quality.  Only current production colors are available through GLC Germersheim. All other colors are available from Messrs. Lindgens. Leather paint Paint spray gun	AR98.00-P-0700-01A *BR00.45-Z-1025-04A *WE58.40-Z-1014-08A
6	Repeat paint application if necessary	 Maintain a drying time of 30 min between applications.	
7	Leave leather paint to dry for approx. 2 h at room temperature		
8	Treat the entire leather cover with leather cleaner		*BR00.45-Z-1006-04A

Workshop equipment/MB testers (see Workshop Equipment Manual)

WE58.40-Z-1014-08A	Paint spray gun SATA-Dekor Z
--------------------	------------------------------

Auxiliary repair materials

Number	Designation	Order number
BR00.45-Z-1006-04A	MB leather cleaner	000 986 05 71
BR00.45-Z-1025-04A	Leather paint	000 986 92 33