GF83.10-P-2101-01GI Air duct locations

The lateral nozzle and side window defroster nozzle (3) air ducts are on the left and right below the instrument panel.


The windshield defroster nozzle air duct (2) is on top of the evaporator housing (front center) below the instrument panel.

The center nozzle air duct (1) is on top of the evaporator housing behind the center nozzle.

The front footwell air duct (4) is integrated in the heater/evaporator housing.

The rear compartment air duct (5) is located below the center console.

The rear footwell air duct (6) is at the bottom next to the rear blower behind the center console.



P83.10-2192-06